

# TrackingTheWorld.com

# **Enduro Plus 4G**

Multi-purpose Tracking Device

**USER MANUAL** 



Document Title	Enduro Plus 4G User manual
Version	1.00
Date	2018-12-16
Status	Release
Document Control ID	TTW-EnduroPlus4G-UM001

### **General Notes**

TrackingTheWorld offers this information as a service to its customers, to support application and engineering efforts that use the products designed by TrackingTheWorld. The information provided is based upon requirements specifically provided to TrackingTheWorld by the customers. TrackingTheWorld has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by TrackingTheWorld within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

### Copyright

This document contains proprietary technical information which is the property of TrackingTheWorld, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © TrackingTheWorld 2018

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 -2 -

### **Contents**

C	ontents		3
0.	Revision his	story	4
1.	Introductio	n	5
2.	Product Ov	erview	6
	2.1. Enduro	Plus 4G Series Products	6
	2.2. Appear	ance	6
	2.3. Button	s/Mini USB Interface Description	6
	2.4. LEDs D	escription	7
	2.5. Externa	al Power Interface	8
	2.5.1.	External DC Charger Interface	8
	2.5.2.	External Battery Interface	8
	2.6. Ignition	Detection	9
	2.7. Externa	al Input Interface	9
3.	Getting Sta	rted	10
	3.1. Parts L	ist	10
	3.2. Battery	Charging	10
	3.3. ENDUR	O PLUS 4G External Cable Interface	11
	3.4. Turn o	n/Turn off	11
4.	Troublesho	oting and Safety info	12
	4.1. Trouble	eshooting	12
	4.2. Safety	info	12

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: <a href="mailto:info@trackingtheworld.com">info@trackingtheworld.com</a> – Website: <a href="www.trackingtheworld.com">www.trackingtheworld.com</a>

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 3 -

# 0. Revision history

Revision	Date	Author	Description of change
1.00	2018/5/25	Kevin Xiang	Initial

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 4 -

### 1. Introduction

The water resistant ENDURO PLUS 4G is a powerful CAT-M1, CAT-NB1, LTE GPS locator designed for lone worker, vehicle, pet and asset tracking applications. The thumb sized button makes this device ideal for applications requiring rapid notification of emergency alert or regular setting of geo-fences based on current location. Its built-in GPS receiver has superior sensitivity and fast time to first fix. Its LTE allows the ENDURO PLUS 4G's location to be monitored in real time or periodically tracked by a backend server and mobile devices. Its built-in 3-axis accelerometer allows motion detection and extends battery life through sophisticated power management algorithms. System integration is straightforward as complete documentation is provided for the full featured @Track protocol. The @Track protocol supports a wide variety of reports including emergency, geo-fence boundary crossings, low battery and scheduled GPS position.

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.


TTW-EnduroPlus4G-UM001 -5-

# 2. Product Overview

### 2.1. Enduro Plus 4G Series Products

Model No.	Region	Technology	LTE Category	Operating Band	Certificate
Enduro Plus 4G-E	Europe	GSM/LTE	eMTC/NB-IoT	GSM: 900/1800 MHz LTE: B3/B8/B20	
Enduro Plus 4G-A	North America	LTE	еМТС	LTE: B2/B4/B12/B13	PTCRB/FCC/ Verizon
Enduro Plus 4G-C	China	GSM/LTE	eMTC/NB-loT	GSM: 900/1800 MHz LTE: B1/B3/B5/B8/B39	

### 2.2. Appearance



## 2.3. Buttons/Mini USB Interface Description

Button / Mini USB Interface Description			
Power Key	•	Turn on ENDURO PLUS 4G Turn off ENDURO PLUS 4G when without charging. (If	
power key is enabled)			

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 6 -

Function Key	<ul> <li>Geo-Fence mode         Long press the key to enable/disable Geo-Fence ID0</li> <li>Geo-Fence in current position mode         Long press the key to enable/disable Geo-Fence ID0. If enable         Geo-Fence ID0, using the current position as the center of         Geo-Fence 0.</li> <li>SOS mode (default)</li> </ul>
Mini USB interface	<ul> <li>Long press the key to activate SOS alarm</li> <li>Connect a 5V DC adapter can power ENDURO PLUS 4G and charge the internal battery</li> <li>Connect a 3.7V Li-ion or Li-Polymer battery can power ENDURO PLUS 4G</li> <li>Backend server developer or administrator can use the Data_Cable_M to configure ENDURO PLUS 4G</li> </ul>

### 2.4. LEDs Description

There are three LED in ENDURO PLUS 4G, their description are as follow:

LED	Event	State
CELL LED	Searching network	Fast flash
	Network has been registered	Slow flash
	Power off	Dark
	SIM-PIN Locked	Solid
	<led on=""> is 2</led>	Dark
GPS LED	GPS has fixed	Solid
	GPS is in fixing	Fast flash
	GPS is on and GPS data wrong	Slow flash
	GPS is off	Dark
	If <led on=""> is 0, 150 seconds later after powers on.</led>	Dark
	<led on=""> is 2</led>	Dark
PWR LED	Power on and normal	Dark
	Charger inserted and charging completed	Solid
	Charger inserted and charging	Fast flash
	Power key was pressed and prepare to power off	Fast flash
	Abnormal	Fast flash
	Power low alert	Slow flash
	Power off or the power light is turned off by	Dark
	command	
	<led on=""> is 2</led>	Dark

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com


Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 -7-

### 2.5. External Power Interface


### 2.5.1. External DC Charger Interface

The Pin2 on Mini-USB connector are used for charging and named as VCHG pin, It can be connected to a 5V DC power supply to power ENDURO PLUS 4G and charge the internal battery.



### 2.5.2. External Battery Interface

The Pin 8 on Mini-USB connector is for external battery and named as EXTBAT pin, It can be connected to 3.7V Li-ion or Li-Polymer battery to power ENDURO PLUS 4G.




For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 8 -

### 2.6. Ignition Detection

The Pin 7 on Mini-USB connector is for ignition detection when ENDURO PLUS 4G is used in vehicle tracking application, It is named as IGN\_IND pin.




Another easy way is to connect PIN7 to a power output in the fuse box of the vehicle which is only enabled after the vehicle is ignition on. For example: the power output for radio FM.

### 2.7. External Input Interface

The Pin 5 on Mini-USB connector is a negative trigger input in newer hardware version. It is named NSW pin. For negative trigger input the electrical conditions are:

Logical State	Electrical State
Active	0V to 0.8V
Inactive	1.7V to 32V or Open

An input example is shown as following figures:



Example of NSW pin connect to a panic button

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 9 -

# 3. Getting Started

### 3.1. Parts List

Name	Picture	Remark
ENDURO PLUS 4G Locater	GPS PWR CEL	GSM/LTE/Cat-M1/LTE Cat- NB1/GPRS/GSM/GNSS/GPS locator
AC-DC Power Adapter (Standard accessory)		It is used to charge the internal battery of ENDURO PLUS 4G.
ENDURO PLUS 4G Data Cable (Optional accessory)		It is the USB data cable which can be used for firmware upgrading and configuration.
ENDURO PLUS 4G External Cable (Optional accessory)		It is the extend cable which include the charger interface and external battery interface on ENDURO PLUS 4G. It also includes the ignition detection interface on the ENDURO PLUS 4G.

### 3.2. Battery Charging

- Please connect AC-DC power adapter with ENDURO PLUS 4G.
- Insert the AC-DC power adapter into the power socket.
- During charging, the PWR LED is flashing fast. When the battery is full charged, the PWR LED will be Ever-light.
- You can also charge the battery by USB cable which connects ENDURO PLUS 4G with the PC.
- Charging time is about 5 hours.

Note: Before using ENDURO PLUS 4G for the first time, please fully charge the battery.


For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 10 -

### 3.3. ENDURO PLUS 4G External Cable Interface

ENDURO PLUS 4G External Cable has a Mini USB connector and six wires which allows the
external power interface, ignition detection and input interface for ENDURO PLUS 4G. Please
find the detail description in the following table.



Color	Name	Remark
RED	External DC IN (5V)	Please refer to 2.5.1 for detail
Black	Ground	Please refer to 2.5.1 for detail
Blue	External Battery IN (DC 3.4V to 4.2V)	Please refer to 2.5.2 for detail
White	Ignition Detect	Please refer to 2.6 for detail
Green	NSW(negative trigger input)	Please refer to 2.7 for detail

### 3.4. Turn on/Turn off

- Turn on:
- ♦ Method 1: Press the Power key at least 3 seconds and release it to turn on ENDURO PLUS 4G. At the same time, PWR LED will also turn on.
- Method 2: Connect device to charger or external battery, and it will turn on automatically, PWR LED will turn on.
- Turn off:
- Method 1: Press the power key about 2 seconds; PWR LED will fast flash and then turn off, it indicates that ENDURO PLUS 4G is turned off. The time of power off is depended on the quality of network. The maximum time of power off is 90 seconds. It is only valid to turn off when using internal battery. Please note the end-user cannot power off ENDURO PLUS 4G when the power key is disabled by protocol.
- Method 2: If using external battery, device power will turn-off when external battery disconnect.

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 11 -

# 4. Troubleshooting and Safety info

### 4.1. Troubleshooting

Trouble	Possible Reason	Solution
After ENDURO PLUS 4G is	The signal is too weak; ENDURO	Please move ENDURO PLUS 4G
turned on, the CEL LED	PLUS 4G can't register to the	into place with good LTE
flashes quickly always.	network.	coverage.
Messages can't be reported	APN is wrong. Some APN cannot	Ask the network operator for
to the backend server by	visit the internet directly.	the right APN.
GPRS.	The IP address or port of the	Make sure the IP address for
	backend server is wrong.	the backend server is an
		identified address in the
		internet.
Unable to power off	The function of power key was	Enable the function of power
ENDURO PLUS 4G.	disabled by <b>AT+GTFKS</b> .	key by AT+GTFKS.
		2
	Unable to power off ENDURO	Disconnect charger or external
	PLUS 4G if charger connected or	battery, and try again.
	using external battery.	
No response from UART	ENDURO PLUS 4G is in power	Remove the Data_Cable_M,
when configure ENDURO	saving mode.	and plug it in again. After this
PLUS 4G through UART		operation, ENDURO PLUS 4G
		will exit from power saving mode for 10 seconds.
		mode for 10 seconds.
		Re-try ENDURO PLUS 4G
		manager tool again, it will try
		to wake up device.
ENDURO DI US 4C con't cot	The CDS signal is weak	Please move ENDURO PLUS 4G
ENDURO PLUS 4G can't get successful GPS fixing.	The GPS signal is weak.	to a place with open sky.
Successiul GF3 lixilig.		· · · · · · · · · · · · · · · · · · ·
		It is better to let the top surface face to sky. (The same
		surface with indication LED)
		Surface With multation LED)

### 4.2. Safety info

- Please do not disassemble the device by yourself.
- Please do not put the device on the overheating or too humid place, avoid exposure to direct sunlight. Too high temperature will damage the device or even cause the battery explosion.
- Please do not use ENDURO PLUS 4G on the airplane or near medical equipment.

For More Information: Please contact TrackingTheWorld, 1633 Bayshore Highway, Suite 390, Burlingame, CA. 94010, USA Phone: +1.650.692.8100 – Email: info@trackingtheworld.com – Website: www.trackingtheworld.com

Copyright © TrackingTheWorld. All rights reserved. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. All trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TTW-EnduroPlus4G-UM001 - 12 -