

WorldTracker Enduro Pro Users Manual



Contents of the Box	1
Sign Up for Service	2
LEDS	3
Viewing Data	4
Downloading Data	5
MapQuest	6
Microsoft BING! Maps	7
Google Earth	8
Reports	9
GeoFences	10
Panic/SOS Alert	11
Troubleshooting	12

For Tech Support call **650-692-2816**

WorldTracker Enduro Pro

1: Contents of the Box

WorldTracker Enduro Pro



Wall Charger



Cellular SIM Card



* The SIM Card is already installed inside of the WorldTracker Enduro Pro. Please keep the credit card sized plastic case.

Screw Driver




Case



WorldTracker Enduro Pro

2: Sign Up for Service

Go to www.TrackingTheWorld.com to sign up.



Please pay the activation fee and sign up for monthly service. The activation of your tracker will not be completed until these payments are received.



TrackingTheWorld.com accepts payment with PayPal or Credit card. You may also call us directly and sign up over the phone.

650-692-2816

8:30-5:00 Monday-Friday

Follow the instructions on the website and provide the required information. Be sure that the name associated with the PayPal account and credit card or bank account match.

There are several options for service. Visit our website for current pricing.

WorldTracker Enduro Pro

3: LEDS




Light	Event	State
GSM Light	Searching network	Fast flash
	Network has been registered	Slow flash
	Power off	Dark
GPS Light	GPS has fixed	Solid
	GPS is in fixing	Fast flash
	GPS is on and GPS data wrong	Slow flash
	GPS is off	Dark
	If "LED On" is not selected, and the GPS LED will not work after turn on 150 seconds.	Dark
Power Light	Power on and normal	Dark
	Charger inserted and charging completed	Solid
	Charger inserted and charging	Fast flash
	Power key was pressed and prepare to power off	Fast flash
	Abnormal	Fast flash
	Power low alert	Slow flash
	Power off or turn off the power light by command	Dark

WorldTracker Enduro Pro

4: Viewing Data

Your map page requires Internet Explorer 8.0 or higher in order to function properly. To view dates, times and speed of a record, move your cursor over a specific point.



Virtual Earth

May 2006						
≤						≥
Sun	Mon	Tue	Wed	Thu	Fri	Sat
30	1	2	3	4	5	6
7	8	9	10	11	12	13
14	15	16	17	18	19	20
21	22	23	24	25	26	27
28	29	30	31	1	2	3
4	5	6	7	8	9	10

Use the calendar to view historical data of the movements your tracker has made. Blue dates have data, white dates do not. To change the month click the arrows on the top left and right.

WorldTracker Enduro Pro

5: Downloading Data

The software automatically saves all location information sent by your tracker to our server. If you wish to keep backups of your tracking data or to use the data in other mapping programs, simply select the date you wish to download using the calendar. Then click on the “Download .csv data” link. The left photo shows the calendar from the current day and the right photo shows the calendar from 2 days before.

FOUND USER:	
Last Report:	41 secs
Altitude:	10
Speed:	1
Course:	271
<input checked="" type="checkbox"/> Refresh:	<input type="text" value="121"/>
Latitude:	
Longitude:	
Download .csv data	

You cannot download data for the current day.

FOUND USER:	
Last Report:	41 secs
Altitude:	10
Speed:	1
Course:	271
<input checked="" type="checkbox"/> Refresh:	<input type="text" value="121"/>
Latitude:	
Longitude:	
Download .csv data	

≤	May 2006						≥
Sun	Mon	Tue	Wed	Thu	Fri	Sat	
30	1	2	3	4	5	6	
7	8	9	10	11	12	13	
14	15	16	17	18	19	20	
21	22	23	24	25	26	27	
28	29	30	31	1	2	3	
4	5	6	7	8	9	10	

Dates which have saved tracking data will appear in blue and the current day will be displayed in yellow.

≤	May 2006						≥
Sun	Mon	Tue	Wed	Thu	Fri	Sat	
30	1	2	3	4	5	6	
7	8	9	10	11	12	13	
14	15	16	17	18	19	20	
21	22	23	24	25	26	27	
28	29	30	31	1	2	3	
4	5	6	7	8	9	10	

WorldTracker Enduro Pro

6: MapQuest

Mapquest is very simple to use. The street view is just like a typical paper map. The aerial view gives an overhead satellite view of the area, the hybrid view uses the satellite images with street names overlaid.





WorldTracker Enduro Pro


7: Microsoft BING! Maps

If you do not see an address when clicking on a breadcrumb, you will need to change your Internet Explorer browser setting. Select the "Tools" drop down menu, and click on "Internet Options..."

Select the "Security" tab.
Then Select "Custom Level."



Make sure that the "Access data sources across domains" option is enabled.



Most major US cities have special "Birds Eye View" mapping. When Birds Eye View mode is available for an area you are viewing, the navigation tool shown to the right will change to allow you to switch to Birds Eye View.

No Birds Eye View Available




Birds Eye View Available


WorldTracker Enduro Pro

8: Google Earth

Download the free version of Google Earth from <http://earth.google.com>.



After installation, select “Google Earth Network Link” under the calendar on your tracking page.




GeoFence

- Right-Click 2 pushpins for trip info.
- Left-Click a pushpin to see the address.



[Google Earth Network Link](#)



Google Earth will automatically open and display the current track on that map.

For help with using Google Earth's features, visit <http://earth.google.com>.

WorldTracker Enduro Pro

9: Reports

Click the “Drive Report” link.
The report will display in a new
window. You must use Internet
Explorer to view the reports.



Driving Report for EXAMPLE on Friday 08 April 2011

ArriveTm	DepartTm	Address	Max Spd	DrvTmMin	Dx	TmParked
	8:23:30 AM	1047 Evans Ct, Hayward, CA	79	25	19.8	
8:48:17 AM	Destination	1641 Bayshore Hwy, Burlingame, CA	0	0	0	
Totals:				0h 25m	19.8 miles	0h 0m

Travel data includes street address, duration of stops, mileage, speed and other daily travel data.

These reports can be printed by selecting “File” and then “Print” from within Internet Explorer.

Stats:

Click the “Stats” link.
The report will display in a new window. You must use Internet Explorer to view the reports.



April 2011 Stats for EXAMPLE

Day	DxDriven	DriveTime	IdleTime	StartTime	StartAdr	EndTime	EndAdr
1	294.3	11.7	6	02:40	1881 Brentz Ln,San Pablo,CA	20:24	5821 Hillcrest Rd,San Pablo,CA
2	245.9	6.6	10.8	06:36	3288 San Pablo Dam Rd,El Sobrante,CA	23:58	3280 San Pablo Dam Rd,El Sobrante,CA
Totals:	540.2 Miles	18.3 hrs	16.8 hrs				

The Stats link allows you to see the data for each day data was sent for the month displayed and the monthly/yearly total are of Miles Driven for each month.

These reports can be printed by selecting “File” and then “Print” from within Internet Explorer.

Miles Driven 2010

Month	EXAMPLE
Jan	0
Feb	0
Mar	0
Apr	0
May	0
Jun	0
Jul	0
Aug	0
Sep	54.6
Oct	0
Nov	0
Dec	0
Total	54.6

WorldTracker Enduro Pro

10: GeoFences

A GeoFence is a virtual fence (a square around a certain location) that you can preset online. When the WorldTracker Enduro Pro enters/leaves the fence, you will receive an alert via email or a text message on your cellular phone by entering a plus symbol, your country code followed by your cellular phone number. You will receive a text message on your phone when the GeoFence has been triggered.

To set up a GeoFence, first click the "GeoFence" button.

Click on the drop down window "Both". Under this menu you can choose whether you want an alert when the vehicle enters and exits, only enters, only exits, or one shot (alert when the vehicle exits one time).

Once a GeoFence is set, it will remain in place until it is deleted. This does not apply for the one shot option.

Enter the email address you wish to receive GeoFence alerts on.

You will need to enter a password. The password is always 0000, unless specified otherwise.


Continue to Next Page.

The image displays two sequential screenshots of the WorldTracker Enduro Pro software interface for setting up a GeoFence. Both screenshots feature a vertical label 'GEO FENCE' on the left and a red '[Help]' button in the top right corner.

The top screenshot shows a single button labeled 'GeoFence' in the center of the screen.

The bottom screenshot shows the next step in the process. It includes a 'Save Fence' button at the top, followed by a dropdown menu currently set to 'Both'. Below the dropdown is a text input field containing the email address 'myemail@mail.com', another text input field labeled 'Password', and a 'Cancel' button at the bottom.

Draw a GeoFence by double clicking on one part of the map and then double clicking again in a different location, surrounding the area you would like to include. An area will be highlighted on the map indicating the GeoFence area. If you are not satisfied, you can repeat this procedure to draw a different GeoFence. Once you are satisfied with the area of the fence, click on “SET”.



This can be repeated multiple times to set multiple GeoFences. To view the GeoFences that are set, click on the GeoFence button. The GeoFences are indicated on the map.

To delete a GeoFence, enter the password and click on “DELETE” indicated on the right-hand part of the GeoFence. A window pops up indicating that the GeoFence has been deleted. You must do this for every GeoFence created.

WorldTracker Enduro Pro

11: Panic/SOS Alert



SOS Button:

When pushed and held down for 2 seconds, the panic button will cause the unit to send an SOS message to the server. You can be notified by email or text message.

These location points will display on your map page with an SOS alert message. The tracker can be programmed to send the alert messages to a cell phone if you prefer.

For more information please call 650-692-2816.



WorldTracker Enduro Pro

12: Troubleshooting

“My tracker has stopped sending data.”

Retrieve your unit and replace or recharge the batteries. Try turning the unit off and plugging it into the 12-volt power adapter. Then turn it back on. If you still do not receive data, the unit may need to be reprogrammed. Please contact our support department for assistance.

“The “FIX LED” does not illuminate.”

The unit should get a GPS location fix within a few minutes.

If you do not receive a fix, take the unit outside and wait for a few minutes while the unit has a clear view of the sky.

“My tracking page displays yesterday’s data.”

Data is not updated on the map until new positions are reported. Look at the time of the “last report” on the map. If the time of the last report is before midnight central standard time, the current data is from the day before. Your tracker may have stopped sending data, please retrieve the tracker for testing.

If you continue to have trouble or need assistance with your tracker, please call our customer support department at 650-692-2816.